


Movement cal. VOSTOK 2415 (2416 without date)



Technical Specifications:

Diameter: 24mm, Height: 6,3mm, 31 Jewels

Central second-hand

19.800 vhp

Accuracy is about -10 to +30 seconds per day.

Power reserve 31 hours

Automatic Winding and Shock-resistance

Manual

1. Before the watch is used the first time it should be wound by rotating the crown. Later the watch will be wound automatically when wearing it.
2. To set the time, please pull out the crown and adjust the time (clockwise). After that press the crown in its initial position (Note for watches with screwed-in crown: first unscrew the crown counter clockwise, then adjust the time by rotating the hands clockwise, finally screw the crown back while slightly pressing it.)

ATTENTION:

- Any Automatic watch should be worn at least 8 hours daily to insure optimal performance!
- Do not rotate the hands counter clockwise at the moment when the time-disc begins to move and the date changes! Wait till the date is changed, then continue adjusting/setting the time/date.

If you follow these instructions and use the watch carefully it will work trouble-free and keep high accuracy for a long time.